

# S + C bands 1.8 m ANTENNA & ANTENNA CONTROL UNIT





## **DESCRIPTION**

This station is designed for signals Receive in the S + C frequency bands.

A friendly Man Machine Interface installed on a PC allows its remote Monitoring & Control via a RS232 serial or TCP/IP link.

**Receive** is made through a **1.8 m dish** equipped with GPS tracking & RF tracking feed in RHCP & LHCP including 0.7 dB NF LNA, and filters.

Target tracking can be achieved through the three main modes: GPS tracking, Manual (through Joystick) and Autotracking

RF Auto Tracking can be performed through either AM/AGC signals delivered by the Telemetry Receiver or a dedicated 2 channels S + C Tracking Receiver.

The station is mainly composed of the following parts:

External two-axis auto-tracking antenna

Electronic compass for automatic north reference. Electronic & spirit level for automatic set-up in option for mobile station.

- <u>Antenna Drive Unit</u> composed of three drawers: the microcontroller drawer, the power supply drawer and the servo power drawer.
- Antenna Control Unit (PC under Windows OS)

#### **SPECIFICATIONS**

#### TM antenna

- Type: 1.8 m dish with primary feed (Single Channels Monopulse)
- Frequency band: 2200-2400 MHz (S band)

: 5090-5250 MHz (C band)

- G/T: 5.5 dB/K typ. @ 2.3 GHz and 15°El angle (23℃)
  - : 10.5 dB/K typ. @ 5170 MHz and 15°EI angle (23°C)
- Polarization: RHCP and LHCP
- 3 dB beamwidth: 5.6°typ. @ 2.3 GHz

: 2.5°typ. @ 5.17 GHz

- Side lobes: < 17 dB

### Pedestal Pedestal

- Type: Elevation over Azimuth
- Elevation range: -5°to +90°or -5°to +185°(in option)
- Azimuth range: unlimited (continuous rotation with rotary joint/slip ring assembly)
- Rotation speed max.: ≥ 25% on both axes
- Acceleration max.: ≥ 30%s<sup>2</sup> typ. on both axes
- Pointing accuracy: ± 0.08° (in manual mode)
- Optical encoders: 12 bits

## **Environmental**

- Storage temperature: -40° to +70℃
- Operating temperature: -30 to +50℃ (outdoor), extended range in option.
- Rain: up to 50 mm/hour
- Relative humidity: 0 to 100% (outdoor)
- Operating wind load: 90 km/h
- Survival wind load: 144 Km/h (up to 210 Km/h in option)

#### **Mechanical**

- Antenna dimensions: 1.8 m
- Total weight (pedestal and dishes): < 300 kg
- Color (antenna and pedestal): RAL9003 (white) or other upon request.

## **Electrical**

- Power supply: through Control & Servo Power Rack
- Pedestal peak consumption: 220 VAC, 50 Hz, 1.2 kVA

#### **OPTIONS:**

- Omni directional antennas for far field or zenith pass operating
- Video/IR system installed at the back of the dish.
- Optical encoders: 13 bits
- Electronic compass & electronic spirit levels
- Dry air pressurization unit for pedestal and feed
- Mechanical structure adapted to mobile version (trailer or shelter mounting)

Commercial & Marketing Department address: 9 rue Ravel—91620 Nozay FRANCE

Tel: + 33 (0)1 69 63 86 30-Fax: + 33 (0)1 69 63 84 74

Contact: Mr. Gerard FOURREAUX Email: gerard.fourreaux@aasystel.com



# S + C Bands 1.8 m ANTENNA & ANTENNA CONTROL UNIT



### **ANTENNA CONTROL UNIT (ACU)**

The dedicated software, through the color display, provides a user friendly interface (see below non contractual example of ACU screen).

The software can easily be customized for user's needs. Touch screen with integrated PC in option

# MONITORING INFORMATION available through the PC Man-Machine Interface

- Elevation and Azimuth pedestal angles
- Selected operating mode
- Tracking signal level (when Auto-tracking mode is active)
- Tracking errors
- Tracking polarization in operation
- Alarms
- Logbook: events (El, Az, Time, antenna speed, received signal level, tracking errors, operating modes...) are recorded with 50ms step.







# OPERATING MODES available through the PC Man- Machine Interface

Elevation and Azimuth axes are independent:

- STOP: Stop on El. and Az.; brakes are switched on
- MANUAL: El. and Az. axes reach the angular positions received through the PC (0 to 360° with 12 bits; s tep = 0.08°)
- SLEW: El. and Az. axes speed adjustment(-20 to +20% w ith 8 bits; step = 0.16%s)
- AUTO-TRACKING: manual or automatic (with tracking error angle criteria or HF signal level criteria)
- GPS: The ACU elaborates El. and/or Az. angles through the target GPS information received by RS232 or TCP/IP link under NMEA 0183 standard. The target range is calculated by the ACU and displayed on the screen.
- SLAVE (option): The ACU elaborates El. and/or Az. angles through the SLAVE information received by TCP/IP link.
- **MEMORY TRACK (with AT mode):** as back up mode in case of auto-tracking lost. When auto-tracking is lost, the antenna continues traveling of Az and El with extrapolated speed.
- **SEARCH** (option): searching around current antenna location (spiral scan)
- PROGRAM TRACK (option): Tracking following a predicted trajectory download from computer.
- PRESET: Up to 10 El. and Az. angles can be stored
- SURVIVAL: El. 90°, brakes applied on El. and Az.
- INITIALIZATION: The ACU calculates the correction to be applied according to the electronic spirit level and compass information
- AUTOTRACKING SUPPORTED BY GPS (with AT mode):

When GPS data from aircraft are available, the operator through the Man Machine Interface, can follow the aircraft and locates the aircraft into the 5 dB antenna pattern.

Starting in AutoTracking mode, if for any reason, the aircraft reaches this " 5 dB circle" then the antenna will automatically switch to GPS tracking mode.

Then when antenna will cross the 2 dB circle on its way back, the antenna will switch automatically in Auto-Tracking mode.

